

XS1

	Конт.	Цепь	Цепь	Конт.
A14	1	A14	A15	2
VSS	3	GND	A10	4
A13	5	A13	A12	6
A6	7	A6	A7	8
A4	9	A4	A5	10
A2	11	A2	A3	12
PAGE	13	/PAGE	A1	14
D4	15	D4	D3	16
/RD	17	/RD	D5	18
D1	19	D1	D0	20
VCC	21	VCC	A0	22
D2	23	D2	D0(P0)	24
AX16	25	D1(P0)	D3(P0)	26
/P0	27	/P0 [BNK7]	D6	28
D7	29	D7	A11	30
A9	31	A9	A8	32
GM	33	GM [BNK6]	/WR	34
	35	[BNK5]	D2(P0)	36

